

NEC SV8100 INMAIL VOICEMAIL QUICK REFERENCE

Accessing Your Mailbox:

- Lift Handset (or press speaker key)
- Press your **VM** soft key(on display) **or** if accessing your mbox from another phone:
- Dial 333, you will then be prompted to enter your mailbox number

Setting a Security Code:

- 1. Press your **VM** soft key
- 2. Press 67
- 3. Press **7**
- 4. Enter new 4 digit security code **DO NOT use passwords like 1234 or 1111. Follow Prompts:
 - a. Press 7 to always be prompted for a security OR
 - b. Press **6** to only be prompted for a security code when accessing your mailbox from off site

Recording Your Name for the Company Directory

- 1. Press your VM key
- 2. Enter 76
- 3. Press 7 or REC (soft key); follow prompts

Recording Your Personal Greeting

- 1. Press your **VM** soft key
- 2. Press **Greet** (or press **4** on dial pad)
- 3. Choose greeting you'd like to record: **Gr 1**("in the office"), **Gr 2** ("Out of Office") **OR Gr 3** ("Holiday")
- 4. Press **Rec** (or press **7** on dial pad), press # to end recording
- 5. Press Lstn (or press 5 on dial pad) to review greeting or Rec to re-record

Example Script:

"You have reached the voicemail of . Please leave a detailed message and I will return your call as soon as possible. To reach reception, press 0. Thank you."



NEC SV8100 INMAIL VOICEMAIL QUICK REFERENCE

Listening to Voicemail Messages

- 1. Press your **VM** soft key
 - Press 5 on dial pad or Lstn soft key to Listen
 - Press 3 on dial pad or Erase soft key to Erase
 - Press 72 on dial pad to Save
 - Press 2 on dial pad or RPT soft key to rewind (5 seconds)
 - Press 4 to Fast Forward (5 seconds)
 - Press 63 to Forward message to another mailbox
 - Press 84 to hear date and time
 - Press 5 on dial pad or Next soft key to skip to Next message

Accessing Your Voicemail From Off Site:

- 1. **Call the main number** (or side door *if* applicable). When auto attendant greeting begins:
- 2. Press # key followed by your Extension Number ex. #101

Note: If an employee answers, have them transfer you in to voicemail by pressing **transfer**, dialing **333**, and then **hanging up** (you will then follow step 2)